



SCH-N361 Quick Reference Card



BASIC OPERATIONS

| | | | |
|-------------------------------|-------------------------|---------------------------|---|
| Make a call | Phone number + | Save a Number | Enter Number + OK + OK + ▶ / ▶ to select Label + OK + Enter Name + OK + ▲ / ▼ to select Entry/Home/Work/Mobile /Pager/Fax/No Label/Speed dial/ E-mail/URL/Group/Name Ringer/Birthday/Secret/Image) + ▶ / ▶ to change the settings or MENU to enter information + OK + OK |
| End a call | | | |
| Receive a call | | | |
| Adjust the key beep volume | (in Standby mode) | | |
| Adjust the speaker volume | (during a conversation) | Speed dialing | Enter Memory Location of the number you want, holding the last digit to automatically dial. |
| Redial the last call | twice | Phonebook Search | Press ▲ + ▶ / ▶ + ▲ / ▼ + OK or |
| Switch to Silent mode | Press and hold # | Access the web browser | Press and hold |

MENU TREE

Main Menu (To access, press the **MENU** key)

1 : Calls

- 1 : Outgoing
- 2 : Incoming
- 3 : Missed
- 4 : Erase History
- 5 : Air Time

5 : Voice Tools

- 1 : Voice Memo
- 2 : Voice Answer

- 1 : Ringer Volume
- 2 : Ringer Type
- 3 : Alerts

2 : Phone Book

- 1 : Find
- 2 : Add New Entry
- 3 : Group Setting
- 4 : My Phone #
- 5 : Memory

7 : Display

- 1 : Menu Style
- 2 : Wallpaper
- 3 : Backlight
- 4 : Banner
- 5 : Dual Clock
- 6 : Service LED
- 7 : Contrast
- 8 : Power Saving

3 : Messages

- 1 : New MSG
- 2 : Voice
- 3 : Inbox
- 4 : Outbox
- 5 : Filled MSG
- 6 : WAP Alerts
- 7 : Erase MSG
- 8 : MSG Setting

8 : Games

- 1 : Fun Bowling
- 2 : Honey Ball
- 3 : Go Hamster

4 : Planner

- 1 : Today
- 2 : Scheduler
- 3 : Task List
- 4 : Memo Pad
- 5 : Alarm
- 6 : Calculator
- 7 : World Time
- 8 : Countdown
- 9 : Set Time

9 : Setup

- 1 : Auto Answer
- 2 : Call Answer
- 3 : Auto Key Lock
- 4 : Auto Retry
- 5 : Set System
- 6 : Data/Fax
- 7 : Version
- 8 : Security