### **D-Link Antenna-kit** Installation Guide

Step 1

Remove the default antenna.



Step 2

Connect the extension cable onto the external connector on device.



### Step 5

Use water-proof tape to wrap around both connectors tightly, as the pictures howed below







### Step 3



Install the surge protector as recommended position when you do not purchase the low loss cables (ANT24-CB03N, ANT24-CB06N and ANT24-09N...)

When install the surge protector









Install the surge protector as recommended position ,near the device side, when you have the low loss cables (ANT24-CB03N, ANT24-CB06N and ANT24-CB09N ...)




With Surge protector (ANT24-SP) adaptor on an outdoor serial is attached to the lightning protection system (ground) of the building. All devices downstream are then protected by the ground from lightning strikes. It can protect your sensitive WLAN equipments from high voltage surges caused by dischargeand transients at the antennas. It will be integrated in the cabling system between the antenna and the coax-cable and must have direct ground contact.

### D-Link ANT24-0400 Indoor Omni-Directional Antenna

Remove one default antenna from the wireless device and start to assemble!

### Compliant with DWL-660 WLAN card






#### **Wall mount**












### **A** CAUTION:

Please always place the antenna vertically to the desk/ceiling, not recommend to mount the antenna perpendicular to the wall.







Horizontal coverage

Vertical coverage


Frequency band	2400-2500MHz
Antenna gain	4dBi
VSWR	2.0 max
Polarization	Linear vertical
HPBW / H-plane	360°
HPBW / E-plane	40°
Impedence	50 Ohms
Dimensions LxWxH	70x48x200 mm
Weight	180g without joint

- ANT24-0400 Antenna
- With 1.5m cable
- Mounting Kit
- Quick Installation Guide




# D-Link ANT24-0401 Ceiling Mount Antenna


Remove one default antenna from the wireless device and start to assemble!






- 1. Carefully remove the antenna from the package.
- 2. Take out the Washer (1 pcs) from the package
- 3. Take out the Flange washer (1 pcs) as well.
- 4. Drill 2 holes through the ceiling board, one to fix the antenna main body with wacher, another for the antenna SMA connector linked onto extension cable which is included within the package.









Horizontal coverage


Vertical coverage

2400-2500MHz
2.5 ~ 3.7 dBi
2.0 max
Linear vertical
360°
50 ~ 75 °
50 Ohms
Ø132x42 mm
110g without joint

- ANT24-0401 Antenna
- Extension Cable (2M)
- Mounting Kit
- Quick Installation Guide

### D-Link ANT24-0500 Indoor/Outdoor Omni- Directional Antenna

Remove one default antenna from the wireless device and start to assemble!




#### **Pole Mount**



#### **Installation Note:**

- 1. use L- type mounting to fix with antenna
- 2. use 4 plastic anchor with (4) screws to install the antenna onto the wall.
- 3. use band clamp (2pcs) to fix the antenna on the pole.




### **A** CAUTION:

Please always place the antenna vertically to the horizontal surface, not recommend to mount the antenna perpendicular to walls.



#### Overlook





Horizontal coverage

Vertical coverage


Frequency band	2400-2500MHz
Antenna gain	5.0 dBi
VSWR	2.0 max
Polarization	Linear vertical
HPBW / H-plane	360°
HPBW / E-plane	32°
Impedence	50 Ohms
Dimensions LxWxH	Ø19x310 mm
Weight	180g without joint


- ANT24-0500 Antenna
- Extension Cable (3m)
- Mounting Kit
- Quick Installation Guide



### D-Link ANT24-0800 Indoor/Outdoor Omni-Directional Antenna


Remove one default antenna from the wireless device and start to assemble!






### **A** CAUTION:

Please always place the antenna vertically to the horizontal surface, not recommend to mount the antenna perpendicular to the wall.







Horizontal coverage


Vertical coverage

Frequency band	2400-2500MHz
Antenna gain	8.0 dBi
VSWR	2.0 max
Polarization	Linear vertical
HPBW / H-plane	360°
HPBW / E-plane	15°
Impedence	50 Ohms
Dimensions LxWxH	Ø19x630 mm
Weight	360g without joint

- ANT24-0800 Antenna
- Extension Cable (50cm)
- Mounting Kit
- Surge Protector
- Water-proof tape
- Quick Installation Guide

### D-Link ANT24-0801 Indoor Directional Panel Antenna


Remove one default antenna from the wireless device and start to assemble!





The following parts are needed for wall mounting:


- 1. plastic wall anchors (4) screws
- 2. wall screws
- 3. mounting base
- 4. locking wheel on the mounting base
- 5. adjustible pivot arm
- 6. locking wheel for pivot arm











Vertical coverage


Frequency band	2400-2500MHz
Antenna gain	8.5 dBi
VSWR	1.5 max
Polarization	Linear vertical
HPBW / H-plane	70°
HPBW / E-plane	70°
Impedence	50 Ohms
Dimensions LxWxH	120x120x43mm
Weight	300g without joint

- ANT24-0801 Antenna
- Extension Cable (3m)
- Mounting Kit
- Surge Protector
- Water-proof tape
- Quick Installation Guide

### D-Link ANT24-1200 Indoor Directional Panel Antenna

Remove one default antenna from the wireless device and start to assemble!







Wall mount with plastic wall plug



Window suction mount with widow suction cup








Frequency band	2400-2500MHz
Antenna gain	11.5 dBi
VSWR	1.5 max
Polarization	Linear vertical
HPBW / H-plane	80°
HPBW / E-plane	23°
Impedence	50 Ohms
Dimensions LxWxH	330x93x20 mm
Weight	190g without joint


- ANT24-1200 Antenna
- Extension Cable (3m)
- Mounting Kit
- Quick Installation Guide


### D-Link ANT24-1200 Outdoor Directional Yagi Antenna


Remove one default antenna from the wireless device and start to assemble!

### **Wall Mount**









Frequency band	2400-2500 MHz
Antenna gain	12 dBi
VSWR	1.5 max
Polarization	Linear vertical
HPBW / H-plane	50°
HPBW / E-plane	50°
Impedence	50 Ohms
Dimensions LxWxH	280x87x48 mm
Weight	300g without joint


- ANT24-1201 antenna
- Extension cable ( 50cm )
- Mounting kit
- Surge protector
- Water-proof tape
- Quick installation guide



## D-Link ANT24-1400 Outdoor Directional Panel Antenna

Remove one default antenna from the wireless device and start to assemble!


#### Wall mount





#### **Installation Note:**

Required parts for wall mounting:

- 1. ANT-1400 antenna body with 2 screw holes
- 2. M-shaped metal fixing
- 3. spring washers 8mm
- 4. bolts M8 x 12
- 5. steel tubes
- 6.8mm washer
- 7. bolt M8 x 110
- 8. nut M8 with lock washer
- 9. bolts M8 x16 with lock washer, washers and nuts
- 10. bolts M6 x10 with washers
- 11. 6mm washers
- 12. triangular stand
- 13. half-round metal stand
- 14. wall screws
- 15. plastic wall anchor









Horizontal coverage Vertical coverage


Frequency band	2400-2500 MHz
Antenna gain	14 dBi
VSWR	1.5 max
Polarization	Linear vertical
HPBW / H-plane	30°
HPBW / E-plane	30°
Impedence	50 Ohms
Dimensions LxWxH	240x240x69 mm
Weight	825g without joint


- ANT24-1400 Antenna
- Extension Cable (50cm)
- Mounting Kit
- Surge protector
- Water-proof tape
- Quick Installation Guide

### D-Link ANT24-1400 Outdoor Directional Panel Antenna










### **D-Link ANT24-1800 Outdoor Directional Panel Antenna**


Remove one default antenna from the wireless device and start to assemble!




### Wall mounting



- ① Mounting base 1 PC
  ② M4\*8 screw+W+S/W 4 PCS
  ③ Space keeper 4 pcs
  ④ M-shape mounting 1 pc
  ⑤ 3/4" screw 4 pcs
  ⑥ Plastic wallplug 4 pcs
  ⑦ M6\*16 screw 4 pcs
  ⑥ M6 S/W 4 pcs
  ⑥ M6 W 4 pcs








Pole	moui	nting
		1



- 1 Mounting base 1 PC
  2 M4\*8 screw+W+S/W 4 PCS
  3 Space keeper 4 pcs
  4 M-shape mounting 1 pc
  6 Pole mount clip 1 pc
  6 M6\*60 screw 2 pcs
  7 M6\*16 screw 4 pcs
  8 M6 S/W 4 pcs
  M6 W 4 pcs




Frequency band	2400-2500 MHz
Antenna gain	18 dBi
VSWR	1.5 max
Polarization	Linear vertical
HPBW / H-plane	15°
HPBW / E-plane	15°
Impedence	50 Ohms
Dimensions LxWxH	360x360x16 mm
Weight	1600g without joint

- ANT24-1800 Antenna
- Extension Cable (50cm)
- Mounting Kit
- Surge protector
- Water-proof tape
- Quick Installation Guide


# D-Link ANT24-1801 Outdoor Directional Yagi Antenna

Remove one default antenna from the wireless device and start to assemble!




### **Installation Note:**

- 1. Main body
- 2. Angle mounting
- 3. Mounting bracket
- 4. 2" pole clamp
- 5. M8x 20 bolt
- 6. M8x 110 bolt
- 7. M8 nut
- 8. M8 washer
- 9. M8 spring washer
- 10. M6-95 screw
- 11. M6 nut
- 12. Band clamp









Frequency band	2400-2500 MHz
Antenna gain	18 dBi
VSWR	1.5 max
Polarization	Linear vertical
HPBW / H-plane	15°
HPBW / E-plane	15°
Impedence	50 Ohms
Dimensions LxWxH	Ø89x1000 mm
Weight	3500g without joint

- ANT24-1801 Antenna
- Extension Cable (50cm)
- Mounting Kit
- Surge protector
- Water-proof tape
- Quick Installation Guide


Right Antenna Links for the Smart Application

### **D-Link Air DWL-M60AT Indoor Directional Panel Antenna**





# **Ceiling mount** Fixed screw on antenna base



Frequency band	2400-2500MHz
Antenna gain	6dBi
VSWR	1.5 max
Polarization	Linear vertical
HPBW / H-plane	80°
HPBW / E-plane	80°
Impedence	50 Ohms
Dimensions HxWxD	115x76x33mm
Weight	110g without joint

### **A** CAUTION:

1. Always place the antenna on a flat or secure

**Wall Mount** 

- 2. Concealing the antenna behind books, cabinets or other office equipment may affect the performance of the wireless networks.
- 3. The antenna transmission range may vary according to different enviornments or applications.

- ANT24-1800 Antenna
- Extension Cable (50cm)
- Mounting Kit
- Surge protector
- Water-proof tape
- Quick Installation Guide